
## SLIDE Prepping The Mold





Apply lubricant to ejector pins. Use a non-marking lubricant on the front of the pins where they touch the molded part. Use a heavier-duty lubricant on the back of pins, inside the mold. Apply short-term rust preventive to critical components and mold surface while mold is out of service overnight. Specialty rust preventives will immediately flash-off when mold is put back into service and don't require a cleaner to remove it.



## Great Solutions Under Pressure • www.SlideProducts.com Over 6 Decades of Mold Care Experience

Slide Products is distributed by

