

SLIDE Proper Mold Care At The Machine

Mold Cleaners

Water is used to control mold temperature.

The platen holds the mold.

Mold cleaner removes resin deposits. Mold cleaning wipes are placed at every station for a convenient quick wipe-down.



Lubricants Dozens of ejector pins require periodic lubrication. Pick a lubricant that won't mark the plastic parts.



Rust Preventives Rust appears in just hours on idle molds. Rust preventive is applied for overnight protection and when the mold is moved to the shop to wait for maintenance.

Condensation appears moisture and neutralizes

during cool-down. Rust preventive displaces fingerprint acids.

Mold Releases Mold release is sprayed over the entire mold or just spots where the plastic part tends to stick or hang up.



Great Solutions Under Pressure • www.SlideProducts.com **Over 6 Decades of Mold Care Experience**

Slide Products is distributed by

www.rshughes.com